ACCUSPLIT®

ACCUSPLIT.

# SURVIVOR™

## PRO SPLIT STOPWATCH

## STOPWATCH OPERATIONS




**SINGLE EVENTS**
R – START
R – STOP
L – RESET

**TIME-IN, TIME-OUT**
R – START
R – STOP
R – RESTART
R – STOP
L – RESET

**LAP SPLIT**
C – PUSH AND RELEASE UNTIL "LAP" APPEARS
R – START
L – SPLIT
L – RETURN TO RUNNING TIME
R – STOP
L – RESET

**CUMULATIVE SPLIT**
C – PUSH AND RELEASE UNTIL "CUM" APPEARS
R – START
L – SPLIT
L – RETURN TO RUNNING TIME
R – STOP
L – RESET

**1,2 FASH FINISH**
C – PUSH AND RELEASE UNTIL "CUM" APPEARS
R – START
L – FINISH #1
R – FINISH #2
L – DISPLAY #2
L – RESET

**BATTERY CHANGING**
See Specifications panel.

**REGISTER NOW** Please return your Survivor Stopwatch Registration to the Repair Center address in the warranty, & we will let you know about future products.

Email (preferred)_____
User_____

**SPECIFICATIONS**

**Batteries:** Batteries should last for 18 months. If display becomes dim, open back and replace with Duracell LR43, Eveready 186, or Ray-O-Vac LR43.

**Operating Temperature:** 14°F to 138°F (–10°C to 59°C).

**Quartz Crystal Accuracy:** 0.04 sec/hr (accuracy may vary with shock, temperature or aging of crystal).

**NO-PROOF-OF-PURCHASE LIMITED WARRANTY**
See label on back of unit for details, or check http://support.ACCUSPLIT.com

**1-800-965-2008 or 1-925-226-0888**
**FAX: 925-463-0147**
**support@accusplit.com**
**www.accusplit.com**

ASSEMBLED IN PRChina
© 2005 ACCUSPLIT

ACCUSPLIT, Inc.
6120 Stoneridge Mall Rd.
Suite 210
Pleasanton, CA 94588 USA
800-965-2008 • 925-226-0888
FAX 925-463-0147
www.ACCUSPLIT.com
support@ACCUSPLIT.com

Downloaded from www.Manualslib.com manuals search engine